

Sentinel™ EFI-MFZ Earth Fault Indicator



PRODUCT BRIEF

KEY FUNCTIONS

- Mains Powered
- Flag Indication
- Remote Indicator Driver
- Auxiliary Relay Contact

FEATURES

- Mains Powered 110-230V~ 50Hz/60Hz
- Electromechanical Flag Indication
- Functionality For Driving Optional Remote Indicator
- Auxiliary Relay Contact Output
- 50A Nominal Trip (Standard)
- 50ms Minimum Fault Duration
- Mains Voltage Reset
- Split-Core Current Sensor
- Maintenance Free
- Manual Test And Reset Via Pushbutton
- IP65 Environment Protection
- Rugged And Reliable Solid State Electronics
- ISO9001 Based Quality Assurance
- Electromagnetic Compatibility