

Sentinel™ EFI-CFZ Earth Fault Indicator

PRODUCT BRIEF



KEY FUNCTIONS

- Current Powered
- Flag Indication
- Remote Indicator Driver
- Auxiliary Relay Contact

FEATURES

- Powered From Load Current
- Electromechanical Flag Indication
- Functionality For Driving Optional Remote Indicator
- Auxiliary Relay Contact Output
- 50A Nominal Trip (Standard)
- 50ms Minimum Fault Duration
- Load Current Reset
- Split-Core Current Sensor
- Split-Core CT Power Supply
- Maintenance Free
- Manual Test And Reset Via Pushbutton
- IP65 Environment Protection
- Rugged And Reliable Solid State Electronics
- ISO9001 Based Quality Assurance
- Electromagnetic Compatibility